

Tire\$aver™

Extend Tire Life • Enhance Safety • Improve Fuel Efficiency • Prevent Under Inflation

2009 MAINTENANCE KIT CROSS REFERENCE

Effective January 1, 2009

MAINTENANCE KIT	TIRESAVER MODELS
MKMTS	MTS-06, MTS-12
MKTS021	Generators w/ plastic bezel that start TS021-0. Covers tank mounts, wall mounts or portables. Does not cover TS02p metal box version.
MKTS123	Generators w/ plastic bezel that start TS051-0, TS076-0 or TS123-0. Covers tank mounts, wall mounts or portables. Does not cover the TS04p or TS051p metal box.
MK-L9000	TS02p, TS04p, TS051p (metal box portables, wall mounts, etc.)
MK-L9001	TS06, TS12, TS18, TS24 (old metal box wall mounts/cabinets)
MKTS20F	TS20F and all variations
MKTS24F	TS24F and all variations
MKTS34F	TS34F and all variations